



Roof Rack Fitting Guide



VEHICLE TYPE MODEL YEARS	FULL-SIZE VANS											COMPACT VANS					OTHER		
	Low-roof						Mid-/High-roof					Ford Transit Connect 2010-2013	Ford Transit Connect 2014+	Ram ProMaster City™ 2015-Present	Chevrolet City Express 2015-Present	Nissan NV200 2014-2021	MercedesMetris 2016-Present	Service Bodies	Box Trucks/Trailers
	Ford Transit 2015-Present	Ford E-Series 1992 - 2013	Chevrolet Express 1996-Present	GMC Savana 1996-Present	Nissan NV 2011-2021	Ford Transit 2015-Present	Ram ProMaster® 2014-Present	Mercedes Sprinter 2007-Present	Nissan NV 2011-2021	Ford Transit Connect 2010-2013	Ford Transit Connect 2014+								
MOUNTING KITS																			
2085-0-01		N/R	N/R	N/R					X	X	X	X	X	X					
2102-0-01	X²	N/R	N/R	N/R		X²													
2130-0-01	X²	N/R	N/R	N/R		X²													
2113-0-01		N/R	N/R	N/R	X			X									X		
2115-0-01		N/R	N/R	N/R			X												
2505		N/R	N/R	N/R													X		
EZGLIDE2™ DROP-DOWN LADDER RACKS																			
2261-3-01										X	X	X	X	X	X				
2265-3-01										X	X	X	X	X	X				
2267-3-01										X	X	X	X	X	X				
2271-3-01	X	X¹	X¹	X¹	X														
2275-3-01	X	X¹	X¹	X¹	X														
2277-3-01	X	X¹	X¹	X¹	X														
2291-3-01						X	X	X	X							X	X		
2295-3-01						X	X	X	X							X	X		
2297-3-01						X	X	X	X							X	X		
ALUMINUM QUICK CLAMP RACKS																			
223-3-03										X	X	X	X	X	X				
224-3-03										X	X	X	X	X	X				
233-3-01		X¹	X¹	X¹															
234-3-01		X¹	X¹	X¹															
233-3-03	X				X														
234-3-03	X				X														
236-3-03	X				X														
ALUMINUM ALL-PURPOSE RACKS																			
209-3-03	X	X¹	X¹	X¹	X	X	X	X	X										
2097-3-03	X	X¹	X¹	X¹	X	X	X	X	X										
218-3-03										X	X	X	X	X	X				
222-3-03										X	X	X	X	X	X				
STEEL ALL-PURPOSE RACKS																			
205-3		X¹	X¹	X¹															
216-3		X¹	X¹	X¹															
2056-3		X¹	X¹	X¹															
20501-3-01	X				X	X	X	X	X										
21501-3-01	X				X	X	X	X	X										
22001-3-01										X	X	X	X						
22002-3-01																X			
22101-3-01										X	X	X	X						
22102-3-01																X			
22501-3-01	X				X	X	X	X	X										
GLIDESAFE LOAD ASSIST																			
23001-3-01	X				X	X	X	X	X										
23003-3-01										X	X	X	X	X					
23004-3-01		X¹	X¹	X¹															

1. Gutter-mounted Van Rack
2. Use 2102-0-01 with 148" WB and 148" XWB Transit 2130-0-01 with 130" WB