



DC Sports
13000 Temple Ave
City of Industry Ca, 91746
T. 626-937-6988
www.dcsports.com

CSB4201
Strut Tower Bar Installation Instructions
2003- 2006 Nissan 350Z

READ ALL INSTRUCTIONS THROUGH COMPLETELY BEFORE BEGINNING INSTALLATION.

IF YOU ARE NOT COMFORTABLE AND/OR FAMILIAR WITH THESE INSTRUCTIONS, PLEASE REFER THIS INSTALLATION TO A QUALIFIED PROFESSIONAL.

WILL NOT CLEAR INTAKE PLENUM SPACER.

TOOLS REQUIRERD
Socket wrench, 14mm socket,
Trim Removal Tool

1. Using the Trim Removal Tool, pop the wiring harness' mounting tabs from the strut bar (Picture A & B).
2. Using the 14mm socket and wrench, remove the 6 bolts and 2 nuts holding down the strut bar to the vehicle. Pull up on the bar to remove from vehicle (Picture C).
3. Install strut bar. Make sure all the bolt holes line up with the bolts (Picture D).
4. Reinstall strut bar nuts and torque down to spec.
5. Check to make sure strut bar clears everything.
6. **RECHECK ALL YOUR WORK.**

PARTS LIST

Quantity	Part Number	Part Description
1	CSB4201	Carbon steel strut bar
2	DCS1008	DC Sports decals



Picture A



Picture B



Picture C



Picture D

THANK YOU FOR CHOOSING DC SPORTS