



TRAILARMOR.COM
839 HWY 2 CORINTH, MS 38834
(662) 233-5700

Installation Instructions

Installation Instructions for Kawasaki Teryx KRX iMpacT Trailing Arm Guards TA012IMPTAG-KAW-KRX

Warnings and Product Liability Disclaimer

This product is intended to be used as a cosmetic accessory under normal equipment operation and should not be depended upon or used as a safety device. Manufacturer assumes no liability for personal injury or equipment damage as the result of use or installation of this accessory. User assumes all risk. User should carefully read all instructions prior to installation.



- Remove tires prior to beginning for easier install. Always secure vehicle with safety stands.
- Locate the passenger side trailing arm guard from the Trail Armor set. Also, locate one supplied #14 x 1-1/4" TEK self-drilling screw and one supplied bowl washer. Holding the guard into position, insert the screw and bowl washer through the pre-drilled hole at the front of the guard. See Picture 1. Tighten securely but do not overtighten.
- Working towards the rear of the vehicle, insert one supplied 1-1/4" screw and bowl washer into each of the other three pre-drilled holes of the guard. See Pictures 2A and 2B. Repeat for the driver side. Replace tires and wheels and check all lug nuts.

