

INSTALLATION INSTRUCTIONS

<u>IMPORTANT NOTICE</u>: Be sure to inspect and test fit product before having it coated or painted. Ranch Hand will not be responsible for the cost of the coating if any problems with fit or finish are not noted and addressed beforehand.

2003-07(Classic) GMC 1500 PICKUP PART # GGG03HBL1

- 1. Open hood and remove plastic cover, then the factory grill. *Note: You can mount the top brackets from underneath the bumper.*
- 2. *Note: There is a driver and passenger top bracket*. They should measure 3 3/4" in height. Remove the top factory bumper bolts and install brackets. Reinstall grill and plastic cover.
- 3. Remove tow hooks if present. They will be reinstalled later. *Note: On the 2005 and 2006 models, remove the cover around the tow hooks.*
- 4. On some trucks, you may have to cut an opening in the bottom plastic of the bumper.
- 5. Slide the leg of the grill guard through the opening of the bumper.
- 6. Bolt the tabs of the grill guard to the top mounting brackets. Place bolts from bottom facing up. Hand tighten only.
- 7. Reinstall tow hooks, if present, into the frame and use factory bolts to mount upright and tow hook to frame. Use ½" bolts to mount upright to frame if no tow hooks. Hand tighten.
- 8. *Note: There is a driver and passenger angle iron bracket*. Bolt angle iron to bottom hole of frame and then bolt bottom of grill guard to angle iron.
- 9. Tighten bolts that mount grill guard to side of frame. Then tighten top mounting bracket bolts. *Note: You can raise grill guard by loosening side bolts of the grill guard and lift grill guard up and retighten bolts.*
- 10. Tighten angle iron bolts.
- 11.MAKE SURE NUTS AND BOLTS ARE TIGHT!

------ WARNING -----