



INSTALLATION INSTRUCTIONS

MAKE: Dodge / RAM

MODEL: 1500/1500 Classic


YEAR: 2009-2018/2019-2022

ENGINE: V8-5.7L

NOTE: Replaces factory dual exhaust only

Cat-Back Exhaust

49-42013-B (Black Tips)
49-42013-P (Polished Tips)



Caution: aFe recommends professional installation on our products. Allow time for your vehicle to cool down prior to installation. When working on or under your vehicle proceed with caution. Exhaust systems reach high temperatures and may cause serious burns. Wear protective safety equipment; eye goggles and gloves to ensure a safe installation.

Step 1: (Read Instructions prior to installation). Remove your stock exhaust from the rear of your truck working your way forward. Disconnect the ground strap from chassis to muffler and save for re-use later. Also take caution not to damage the factory isolation mounts as they will be reused. **It is recommended to not fully tighten the clamps until the entire system has been installed.**

Step 2: For ease of installation spread the pieces of the exhaust along side of your vehicle according to the diagram shown.

Step 3: Install muffler assembly with 3" band clamp. Do not fully tighten.

Step 4: Install the over-axle tubes with 3" band clamp, utilizing the factory isolation mount for left over-axle tube, do not fully tighten.

Step 5: Install tailpipes with 3" band clamp but do not tighten until tips have been centered in the bumper cut outs.

Step 6: Adjust for alignment, tighten all connections and reattach ground strap. Your installation is now complete. It is recommended to retighten all exhaust components after the first 50-100 miles.